







master

S 50 TB

Bedienungsanleitung
Operating Instructions
Istruzioni d'uso
Notice d'utilisation
Instrucciones para el manejo
Instruções de utilização
Gebruiksaanwijzing
Betjeningsvejledning
Bruksanvisning
Käyttöohje
Bruksanvisning
Οδηγίες χειρισμού
Kullanım kılavuzu
Instrukcja obsługi
Kezelési Utasítás
Návod k obsluze
Návod na obsluhu
Instrucțiuni de utilizare
Navodila za uporabo
Ръководство на потребителя
Kasutusjuhend
Vartojimo informacija
Eksploatacījas instrukcija
Руководство по эксплуатации







Safe operation of this tool is possible only when the operating instructions and the safety precautions are read completely and the instructions contained therein are strictly observed.



Always inspect cable and plug before using tool. Only have damage repaired by a qualified professional. Make sure drill is switched off before inserting plug in socket.



The tool must not be damp and must not be operated in a wet environment.

- Wear sturdy shoes.
- For long hair, wear hair protection.
- Always direct the cable to the rear away from the machine.
- Connect machines that are used in the open via a residual current device (RCD) with an actuating current of 30 mA maximum. Use only extension cables that are approved for outdoor use.

- Only work with undamaged insert.
- Beware of any concealed electric cables, gas or water conduits; check the working area with a metal detector, for example.
- Only connect the power plug when the tool is OFF. Disconnect the power plug after use.
- Always disconnect the power plug before performing any work on the tool. Do not carry the tool by the power cord.
- Always keep the extension cable well away from the workplace.
- The tool must not be used without supervision.
- Keep the tool and accessories out of the reach of children.
- Do not drill into the housing or fasten rivets to it for marking or identification of the machine. The double insulation is then no longer ensured. Use stickers.
- Only use original WÜRTH accessories.**

 For further notes on safety refer to enclosed sheet.

Tool Specifications

Dry Wall Screwdriver	S 50 TB
Order number	0702 050 X
Rated input	500 W
Output	255 W
No-load speed	0 – 4 650 r.p.m.
Tool holder	1/4 "
Screw Ø	5.0 mm
Torque at rated load	0.67 Nm
Weight approx.	1.5 kg
Protection rating	□ / II

Operating Controls

- 1 Screwdriver bit
- 2 Bit stop
- 3 Bit holder
- 4 Adjustment ring for depth stop
- 5 Belt hook
- 6 Selector switch for clockwise and anti-clockwise rotation
- 7 Lock-on button for continuous operation
- 8 ON/OFF switch
- 9 Mains cable module
- 10 Latch, mains cable module

Not all of the accessories illustrated or described are included as standard delivery.

Intended Use

This machine is intended for driving dry wall screws in and out.

For damage caused by usage other than intended, the user is responsible.

Initial Operation

Always use the correct supply voltage: The power supply voltage must match the information quoted on the tool identification plate.

Mains cable

Damaged mains cables should not be used. They are to be replaced without delay.

Press the latches **10** on both sides and pull the mains cable module **9** out of the handle.

Use the mains cable module provided only for Würth Electro-Tools. Do not attempt to operate other machines with the module.

Switching ON/OFF

Switching ON: Press ON/OFF switch **8**. Speed according to how far the switch is pressed in.

Switching OFF: To turn off, release ON/OFF switch **8**.

Locking for Continuous Mode

When the ON/OFF switch **8** is fully pressed in (= maximum speed) press the locking button **7**.

To release, press ON/OFF switch **8** again and then let go.

Electronic speed control

The speed can be controlled infinitely variably in the range 0–4 650 r.p.m. and adapted for processing various materials and applications.

Continuous operation under strong load and low speed can overheat the motor.

Allow the motor to cool down in no-load when set at a high speed!

Rotation direction selector

Pressing the rotation direction selector **6** as far as it will go causes the drill to rotate in the corresponding direction.

Attention! Change direction of rotation only when the motor has ceased turning!

Instructions For Use

Bit

To replace the bit **1**, pull off the depth stop **2**. The bit can then be pulled from the bit holder **3** and a new bit inserted. Replace the depth stop.

Clutch

The screw can be placed on the still standing bit while the machine is running. The clutch engages only after applying pressure while screwing. When the depth stop comes to rest on the surface, the clutch is disengaged. The bit again comes to a stop.

Depth stop

The adjustment of the screwing depth takes place with the adjustment ring **4**.

1 Revolution = 1.4 mm

Turning to the right (see Fig. A):

The screw is set deeper.

Turning to the left (see Fig. B):

The screw is set less deep.

To determine the screw depth, it is recommended to begin with a low depth setting and readjust to the final depth.

Maintenance and Cleaning

Before any work on the tool itself, pull the mains plug.

Carry out the following once a week, or more often if the power tool is used more frequently:

- Clean the venting openings.
- Blow out the motor space from outside with dry compressed air.

If the machine should happen to fail despite the care taken in manufacture and testing, repair should be carried out by an authorized customer service agent for Würth power tools.

For all correspondence and spare parts orders, always include the article number on the type plate of the machine.

For the current spare parts list of this machine, log into the Internet under "<http://www.wuerth.com/partsmanager>" or ask for a copy at your nearest Würth branch office.

Environmental Protection



Recycle raw materials instead of disposing as waste

The machine, accessories and packaging should be sorted for environmental-friendly recycling.

The plastic components are labelled for categorized recycling.

Warranty

For this Würth tool, we provide a warranty in accordance with statutory/country-specific regulations from the date of purchase (proof of purchase by invoice or delivery note). Damage that has occurred will be corrected by replacement or repair.

Damage caused by normal wear, overloading or improper handling is excluded from the warranty.

Claims can be recognised only when the tool is presented undisassembled to a Würth branch office or a Würth field service employee.

Noise/Vibration Information

Typically the A-weighted sound pressure level of the tool is 76 dB (A). The noise level when working can exceed 85 dB (A).

Wear ear protection!

The typical hand-arm vibration is below 2.5 m/s².

CE Declaration of Conformity

We declare under our sole responsibility that this product is in conformity with the following standards or standardization documents: EN 55 014-1, EN 55 014-2, EN 60 745-1, EN 60 745-2-2, EN 61 000-3-2, EN 61 000-3-3 according to the provisions of the regulations 73/23/EC, 98/37/EC, 89/336/EEC.

CE 04

Adolf Würth GmbH & Co. KG

A handwritten signature in black ink, appearing to read 'M. Wölflé'.

M. Wölflé

A handwritten signature in black ink, appearing to read 'R. Bauer'.

R. Bauer

Würth worldwide:

Würth Albania Ltd.

Rr. Asim Vokshi
Pall 49/1 Ap. 9
Al-Tirana
Albania
Tel. +355/42/29748
Fax. +355/42/29748
wuerthal@cc.al.edu.org

Würth Armenia Co. Ltd.

63 Tigran Mets Ave.
AM-375005 Yerevan
Armenia
Tel. +3741/559970
Fax. +3741/559972
wuerth@armco.com

Würth Handelsges.m.b.H.

Würth Strasse 1
AT-3071 Böheimkirchen
Austria
Tel. +43/2743/70700
Fax. +43/2743/70703333
info@wuerth.at

Würth Australia Pty Ltd

4 Redwood Drive
AU-Dingly Vic 3172
Australia
Tel. +61/3/95517244
Fax. +61/3/95512994
info@wurth.com.au

Würth Astur Ltd

Mir Galati Str. 63
AZ-370134 Baku
Azerbaijan
Tel. +994/12/601934
Fax. +994/12/601934
wuerth@azdata.net

Würth BH d.d.

Dzamel Biedla 162
BA-71000 Sarajevo, BiH
Bosnia
Tel. +387/33/461770
Fax. +387/33/461825

Würth Belux N.V.

Everdongenlaan 29
BE-2300 Turnhout
Belgium
Tel. +32/14/445566
Fax. +32/14/423077
info@wurth.be

Würth Bulgaria EOOD

Iskarsko Choussee Boul. 12
BG-1592 Sofia
Bulgaria
Tel. +359/2/9659955
Fax. +359/2/9659966
wuerth_bg@bim.net

Würth Belarus Ltd.

Botanicheskaja Str. 5a-603
BY-220038 Minsk
Belarus
Tel. +375/172/363919
Fax. +375/172/852512
wuerthbel@open.by

Würth AG

Dornymweg 11
CH-4144 Arlesheim
Switzerland
Tel. +41/61/7059111
Fax. +41/61/7059494
info@wuerth-ag.ch

Würth Guangzhou

International Trading Co., Ltd.
Room 601, North Tower,
Nantian Building,
3 Jianguang Road
Tianhe High and New
Technology
Industry Development Zone
CN-510663 Guangzhou
China
Tel. +86/20/85552840
Fax. +86/20/855550245
wurzhang@public.guangzhou.gd.cn

Würth Hong Kong Co. Ltd.

Unit B 6/F Prince Ind Bldg
106 King Fok St.
San Po Kong, Kowloon
CN-Hong Kong
China
Tel. +85/2/27508118
Fax. +85/2/27530084
info@wurth-hk.com

Würth China-Shanghai

Langfang Trading Co., Ltd.
2nd Floor (West)
No. 18 Factory Site
No. 481 Gu Ping Road
CN-200233 Shanghai
China
Tel. +86/21/64951418
Fax. +86/21/64848610
wuerthcn@public3.cta.net.cn

Würth Tianjin International Trade Co., Ltd.

Jie Fang Yuan Lu Str. 518-1
CN-300221 Tianjin
China
Tel. +86/22/88242263
Fax. +86/22/88243813
tjwuerth@public.tpt.tj.cn

Wuerth Cyprus LTD

Strovolos industrial estate
P.O. Box 3899
CY-2083 Nicosia
Cyprus
Tel. +357/22/512086
Fax. +357/22/512091
wuerthcy@cytanet.com.cy

Würth, spol. s r.o.

Sazeková 5
CZ-10800 Praha 10
Czech Republic
Tel. +420/2/72106111
Fax. +420/2/72106119
info@wuerth.cz

Würth GmbH & Co. KG

Postfach
D-73503 Künzelsau
Reinhold-Würth-Str. 12-16
DE-74653 Künzelsau
Germany
Tel. +49/7940/15/0
Fax. +49/7940/15/1000
info@wuerth.com

Würth Denmark A/S

Møllegaardsvej 6
DK-6000 Kalundborg
Denmark
Tel. +45/79/323232
Fax. +45/75/517250
wuerth@data.net

Würth Estonia AS

Liimi 3 A
EE-10621 Tallinn
Estonia
Tel. +372/6563509
Fax. +372/6563494
wuerth@eurt.ee

Würth Egypt For Trading S.A.E.

27th. Km Alexandria Cairo
Desert Road, Behind Mercedes
EG-Amriya Alexandria
Egypt
Tel. +2/03/4700432
Fax. +2/03/4700432
wuerth@wuerthegypt.com

Würth España S.A.

Pollanco Riera de Caldes
Carriar Dells Jorcas 23
ES-08184 Palau de Plegamans
Barcelona
Spain
Tel. +34/93/8629500
Fax. +34/93/8646203
webmaster@wuerth.es

Würth Oy

Herajoki
FI-11710 Riihimäki
Finland
Tel. +358/19/77071
Fax. +358/19/7729011

Würth France S.A.

Z.I. Ouest
Rue Georges Besse
FR-67158 Erstein Cedex
France
Tel. +33/3/88645300
Fax. +33/3/88646200

Würth U.K. Ltd.

1 Centurion Way
Eriih
GB-Kent DA 18 4 AE
Great Britain
Tel. +44/208/3196000
Fax. +44/208/3196400
info@wurth.co.uk

Würth Georgia Ltd.

Marshall Gelovani Avenue 36
GE-380059 Tbilisi
Georgia
Tel. +995/32/530610
Fax. +995/32/250610
gewerth@geccaucus.net

Würth Hellas S.A.

23. Klm. National Road
Athens-Lamia
145 68 Krioneri Attikis
P.O. Box 51877
Attikis
GR-145 02 Agios Stefanos
Greece
Tel. +30/1/6290800
Fax. +30/1/8134756
info@wurth.gr

Würth-Hrvatska d.o.o.

Franje Lukova 23/III
HR-1000 Zagreb
Croatia
Tel. +385/1/3498784
Fax. +385/1/3498783
wurth.hr@vnet.hr

Würth Szerelési technika KFT

Gyár utca 2
HU-2040 Budaörs
Hungary
Tel. +36/23/4211730
Fax. +36/23/421777
wuerth@wurth.hu

PT Wuerth Indeh

Jl. Meryua Iri Raya No. 82 A-B
ID-Jakarta 11360
Indonesia
Tel. +62/21/5860036
Fax. +62/21/5861403
wuerth@idola.net.id

Würth Ireland Ltd.

Monacline Industrial Estate
Ballysimon Road
IR-Limerick
Ireland
Tel. +353/61/412911
Fax. +353/61/412428
wuerth@ireland.ie

Würth Israel Ltd.

Azon Halavor 2
Zone 1
IL-Caesaria Industrial Park
P.O. Box 3585
IL-Caesaria Industrial Park
Zip 38900
Israel
Tel. +972/4/6273939
Fax. +972/4/6270999

Wuerth India Pvt. Ltd.

33, Santosh Building,
Marol Co-operative Industrial
Estate,
M V Road, Andheri (East)
IN-Mumbai 400 059
India
Tel. +91/22/8507203
Fax. +91/22/8507020
wuerth@bom4.vsnl.net.in

Würth Teheran Ltd.

Pasdaran St.-Corner of
Negarestane S-No.183
IR-16619 Teheran-Iran
Iran
Tel. +98/21/2842828
Fax. +98/21/2856171
wuerthtehran@irost.com

Vürth à Islandi ehf.

Vesluhraun 5
IS-2100 Garðabær
Iceland
Tel. +354/5302000
Fax. +354/5302001
ebse@wurth.is

Würth S.r.l. - GmbH

Via Stazione, 51
I-39044 Egna (BZ) 111
Tel. +39/0471/828 111
Fax. +39/0471/828 600
vendite@wurth.com

Würth-Jardan Co. Ltd.

Al-yaddouh
Jordan
P.O. Box 951
JO-Amman-11592
Jordan
Tel. +962/6/4122512
Fax. +962/6/4122510
wurthjor@go.com.jo

Würth Japan Co., Ltd.

MT Building
33 Sanmaicho, Kanagawa-ku
JP-Yokohama 221-0862
Japan
Tel. +81/45/4884186
Fax. +81/45/4884187
sot.yed@wurth.co.jp

Würth Nippon GmbH & Co. KG

67 Tsuruja Bldg., 1-29-15
Shinyokohama, Kohoku-Ku
JP-Yokohama 222-0033
Japan
Tel. +81/45/4704633
jwenn@poem.ocn.ne.jp

Wuerth Kenya Ltd.

P.O. BOX 16751
Meru Road
KE-Mombasa
Kenya
Tel. +254/11/312403
Fax. +254/11/312437
wuerth@africaonline.co.ke

Würth Foreign Swiss Company Ltd.

3 Ekki Kövlervegur
KG-Bíshkeq, 720040
Kyrgyzstan
Tel. +996/312/227976
Fax. +996/312/661025
wurth@mfkko.bishkek.sw

Würth Kosovo

No. 36 Pashe Dibra
Bregu i diellit
Prishtine
Tel. +377/44/186514
wurthkosovo@hotmail.com

Würth Korea Co. Ltd.

128-1, O-Keum Dong,
KR-Song Pa-Gu, Seoul, Korea
(138-859)
South Korea
Tel. +82/2/4009311
Fax. +82/2/4009315
wurth-kr@wurth.co.kr

Wuerth Kazakhstan Ltd.

Abai 125, 2nd floor
KZ-480008, Almaty
Kazakhstan
Tel. +7/3272/622432
Fax. +7/3272/622495
wurthkz@kaznet.kz

Würth Lietuva

Darius ir Gireno 21
LT-2038 Vilnius
Lithuania
Tel. +370/2/263045
Fax. +370/2/264108
info@wurth.lt

Würth Reinsurance Company, S.A.

B.P. 2217
L-1022 Luxembourg
Siège social
65, Avenue de la gare
LU-1611 Luxembourg
Tel. +352/491717
Fax. +352/4941188

Würth Maroc SARL

48 Avenue Pasteur
MA-Casablanca 20150
Marocco
Tel. +212/2/2405700
Fax. +212/2/2405706

Würth Moldova Ltd.

Is-Julian cel Mare, nr.4
Hotel National
MD-Chisinau
Moldavia
Tel. +373/2/540398
Fax. +373/2/540398

Würth Makedonia GmbH ul.

Gorice Petrov 108a
MK-91000 Skopje
Macedonia
Tel. +389/233/2230
Fax. +389/233/2083
wurthmk@unet.com.mk

Würth Caribes Sarl

St. Cocotte Canal
MQ-97224 Ducos-Martinique
Tel. +596/560791
Fax. +596/564369
wurth.caribes@wanadoo.fr

Würth Limited

Würth House
Trijq il-Masgar
MT-Gormi QRM09
Malta
Tel. +356/4464604
Fax. +356/441081
wurth@malnet.net

Wuerth (Malaysia) Sdn. Bhd.

6, Jalan Pemas 9/13
Taman Pemas Jaya
MY-81750 Masai Johor
Malaysia
Tel. +60/7/3876280
Fax. +60/7/3887172
wurth@po.jaring.my

Würth Nederland B.V.

Moeskampweg 13
NL-5222 AW 't Hertogenbosch
Postbus 344
NL-5201 AH 't Hertogenbosch
Netherlands
Tel. +31/373/629191
Fax. +31/373/613137
info@wurth.nl

Würth Norge AS

Postboks 84
NO-1483 Skjotta
Mortevien 12, Gjellerasen
Næringsparken
NO-1481 Hagan
Norway
Tel. +47/670/62500
Fax. +47/670/62711
kontakt@wurth.no

Würth New Zealand Ltd.

42 Hobill Avenue,
P.O. Box 97079
3 Ekki Kövlervegur
Manukau City
NZ-South Auckland/Mail
Centre
New Zealand
Tel. +64/9/2623040
Fax. +64/9/2623030
info@wurth.co.nz

Wuerth Philippines, Inc.

Air-Rich Building,
Km. 19.5 East Service Road,
South Expressway
PH-Parañaque City,
Philippines
Tel. +63/2/8382697
Fax. +63/2/8382195
wuerthphil@pacific.net.ph

Würth Polska Sp. z o.o.

ul. Plochinska 33
PL-03-004 Warszawa
Poland
Tel. +48/22/819041
Fax. +48/22/8117190
biuro@wurth.pl

Würth Portugal Technica de Montagem, Lda.

Estrada Nacional, 249-4
Abrunhosa
PT-21-089 Sintra
Portugal
Tel. +351/21/9157200
Fax. +351/21/9151038
wurth.portugal@mail.telepac.pt

Würth Romania S.R.L.

Zapada Mielior 16-18
Sector 1
RO-Bucarest 71529
Romania
Tel. +40/01/2323882
Fax. +40/01/2323893
wuerth@moon.ro

Wuerth Mittelrussland c/o Lagovaz

Transportnija Ul. 20
RU-394043 Voronezh
Russia
Tel. +7/0732/727065
Fax. +7/0732/727065
wurth@wurth.vrn.ru

Würth Irtysh

Ul. Dobrovolskaja 8/1
RU-644099 Omsk
Russia
Tel. +7/0732/425291
Fax. +7/0732/425291
rus@wuerth.omsk.ru

Würth Ukraine Ltd.

Maschynivna, 44
UA-Kiev 03680
Ukraine
Tel. +380/44/4466376
Fax. +380/44/4466467
kiew@wuerth.ua

Würth Central Purchasing

91 Grant Street
US-Ramsey, NJ 07446
USA
Tel. +1/201/9951111
Fax. +1/201/9959908

Würth Technik

Halkar Dulligi 132-1
UZ-706800 Navoi
Uzbekistan
Tel. +998/79/2235207
Fax. +998/79/2235207
danijar@wuerth.com.uz

Cong by TNHH Vu Viet

9/3 Ly Van Phuc-
Tan Dinh Ward- Dist 1
VN-Ho Chi Minh City
Vietnam
Tel. +84/8/8205636
Fax. +84/8/8205634
vuvieth@hcm.vnn.vn

Würth S. Petersburg

Prospekt Dunaiski 68
RU-192 288 St. Petersburg
Russia
Tel. +7/812/1726166
Fax. +7/812/1726085
web@wurth.spb.ru

ZAO Wuerth-Ural

Institutskaja, 6, of. 202
RU-620016 Ekaterinburg
Russia
Tel. +7/3432/432393
Fax. +7/3432/432393
wurth_ural@ur.ru

ZAO Wuerth-Volga

Novosadovaja st., 221, of. 205
RU-443011 Samara
Russia
Tel. +7/8462/703252
Fax. +7/8462/703252
wurth_ural@ur.ru

ZAO Wuerth-Ural

Institutskaja, 6, of. 202
RU-620016 Ekaterinburg
Russia
Tel. +7/3432/432393
Fax. +7/3432/432393
wurth_ural@ur.ru

Würth Svenska AB

Wurth s vgg
Hjalmisberget
Box 1705
SE-70117 Örebro
Sweden
Tel. +46/19/351000
Fax. +46/19/351001

Würth Singapore Pte. Ltd.

Bukit Batok Central Post Office
P.O. Box 365
SG-Singapore 916513
Tel. +65/487/4238
Fax. Box 1705

Würth d.o.o.

Plenljuba 86
SI-1210 Ljubljana
Slovenia
Tel. +386/1/5128890
Fax. +386/1/5121472
wurth@siol.net

Würth s.r.o.

Přibylinská ul. c. 2
SK-83104 Bratislava
Slovakia
Tel. +421/7/49201211
Fax. +421/7/49201299
wuerth@wurth.sk

Würth Verbindungs-technik Co., Ltd.

41/198 Sukhotasawad Road
TH-Ladprao Bangkok 10230
Thailand
Tel. +666/2/9078880
Fax. +666/2/9078877
master@wuerth-th.com

Würth Otomativ ve Montaj

San. Ürün. Paft. Ltd. Str.
Eski Silivri Caddesi No. 29
TR-34200 Mirdasın
Büyükdere
Turkey
Tel. +90/212/8634603
Fax. +90/212/8634608
info@wurth.com.tr

Würth Taiwan Co., Ltd.

4th Fl., 28 Lane 80,
Sec. 3 Non-Kang Rd.,
TW-Taipei, Taiwan, R.O.C.
Taiwan
Tel. +886/2/2787521
Fax. +886/2/27875207
wurth@qcn.net.tw

Würth Ukraine Ltd.

Maschynivna, 44
UA-Kiev 03680
Ukraine
Tel. +380/44/4466376
Fax. +380/44/4466467
kiew@wuerth.ua

Würth Central Purchasing

91 Grant Street
US-Ramsey, NJ 07446
USA
Tel. +1/201/9951111
Fax. +1/201/9959908

Würth Technik

Halkar Dulligi 132-1
UZ-706800 Navoi
Uzbekistan
Tel. +998/79/2235207
Fax. +998/79/2235207
danijar@wuerth.com.uz

Cong by TNHH Vu Viet

9/3 Ly Van Phuc-
Tan Dinh Ward- Dist 1
VN-Ho Chi Minh City
Vietnam
Tel. +84/8/8205636
Fax. +84/8/8205634
vuvieth@hcm.vnn.vn

Würth d.o.o. za trgovinu

monlatzonom opremom
Zrenjaninjska 153 h
YU-1121 Beograd
Yugoslavia
Tel. +381/11/3320198
Fax. +381/11/3320242
wurth_yu@eunet.yu

Würth South Africa Co (Pty) Ltd.

P.O. Box 616
ZA-1811 Boksburg
South Africa
Tel. +27/11/9747191
Fax. +27/11/9746169
wurthso@wurth.co.za

Niederlassungen:

Aachen
Jülicher Straße 236-248
52070 Aachen
Telefon (02 41) 5 68 79 70
Telefax (02 41) 5 68 79 50
nl.aachen@wuerth.com

Aalen
Robert-Bosch-Straße 47
73431 Aalen
Telefon (0 73 61) 92 30 30
Telefax (0 73 61) 92 30 50
nl.aalen@wuerth.com

Augsburg
Flotowstraße 15
86368 Gersthahn
Telefon (08 21) 2 97 61 20
Telefax (08 21) 2 97 61 20
nl.augsburg@wuerth.com

Backnang
Gewerbegebiet, Backnang-Süd
Beim Erlenväldchen 8
71522 Backnang
Telefon (0 71 91) 90 40 40
Telefax (0 71 91) 90 40 50
nl.backnang@wuerth.com

Bad Mergentheim
Im Hauptort Würth, Gebäude 1
97980 Bad Mergentheim
Telefon (0 79 31) 9 24 05 0
Telefax (0 79 31) 9 24 05 10
nl.bad-mergentheim@wuerth.com

Bamberg
Biegenhofstraße 24
96103 Hollstadt
Telefon (09 51) 7 00 84 80
Telefax (09 51) 7 00 84 50
nl.bamberg@wuerth.com

Bayreuth
Hasenweg 6
54488 Bayreuth
Telefon (09 21) 7 92 05 00
Telefax (09 21) 7 92 05 50
nl.bayreuth@wuerth.com

Berlin-Charlottenburg
Spandauer Damm 60-64
10559 Berlin
Telefon (0 30) 32 67 84 30
Telefax (0 30) 32 67 83 51
nl.berlin-charlottenburg@wuerth.com

Berlin-Hohenschönhausen
Grenzschützenhäusern
Hrenzgrabenstraße 4
13053 Berlin
Telefon (0 30) 98 60 01 55
Telefax (0 30) 98 60 01 55
nl.berlin-hohenschoenhausen@wuerth.com

Berlin-Reinickendorf
Oranienhof
Seestraße/Oudendorferstraße 16
13347 Berlin
Telefon (0 30) 405 08 27 60
Telefax (0 30) 405 08 27 53
nl.berlin-reinickendorf@wuerth.com

Biberach
Riss-Center
Riss-Straße 19
88400 Biberach
Telefon (0 73 51) 5 87 98 50
Telefax (0 73 51) 5 87 98 50
nl.biberach@wuerth.com

Bielefeld
Oliver Hilligesser Str. 37
33699 Bielefeld
Telefon (05 21) 9 24 18 10
Telefax (05 21) 9 24 18 27
nl.bielefeld@wuerth.com

Bochum
Harpen Feld 27
44805 Bochum
Telefon (02 34) 9 55 43 03
Telefax (02 34) 9 55 43 50
nl.bochum@wuerth.com

Böblingen
Hanns-Klemm-Straße 46
71034 Böblingen-Hulb
Telefon (0 70 31) 2 11 76 0
Telefax (0 70 31) 2 11 76 50
nl.boebingen@wuerth.com

Braunschweig
Hansestraße 66
38112 Braunschweig
Telefon (05 31) 5 54 78 90
Telefax (05 31) 5 54 78 90
nl.braunschweig@wuerth.com

Bremen
Gewerbegebiet Bayernstraße
Straubinger Straße 11
28219 Bremen
Telefon (04 21) 3 99 88 80
Telefax (04 21) 3 99 88 51
nl.bremen@wuerth.com

Chemnitz
Gewerbegebiet
Südring/Neefestraße
Carl-Linné-Straße 5
09116 Chemnitz
Telefon (03 71) 2 71 47 0
Telefax (03 71) 2 71 47 50
nl.chemnitz@wuerth.com

Cottbus
Gewerbegebiet
An der Reichsbahn
Am Gleis 15
03042 Cottbus-Sandow
Telefon (03 55) 7 56 61 00
Telefax (03 55) 7 56 61 50
nl.cottbus@wuerth.com

Craillheim
Industriegebiet Zur Flügelsau
Rudolf-Richter Straße 60
74564 Craillheim
Telefon (0 79 51) 96 37 0
Telefax (0 79 51) 96 37 50
nl.craillheim@wuerth.com

Darmstadt
Weiterstraße Park
Brunnenweg 19
64331 Weiterstadt
Telefon (0 61 50) 18 18 10
Telefax (0 61 50) 18 18 50
nl.darmstadt@wuerth.com

Dortmund
Wilhelmstraße 35A
59439 Holscheid
Telefon (0 20 03) 91 12 62 0
Telefax (0 20 03) 91 26 50
nl.dortmund@wuerth.com

Dresden-Löbtau
Vollersstraße 37
01159 Dresden
Telefon (03 51) 4 38 47 0
Telefax (03 51) 4 38 47 50
nl.dresden-loebtau@wuerth.com

Dresden-Mickten
Marie-Curie-Straße 6
01139 Dresden
Telefon (03 51) 4 14 53 0
Telefax (03 51) 4 14 53 50
nl.dresden-mickten@wuerth.com

Düsseldorf
Lierenfelder Straße 53
40231 Düsseldorf
Postfach 103532
40046 Düsseldorf
Telefon (02 11) 9 73 06 0
Telefax (02 11) 9 73 06 50
nl.duesseldorf@wuerth.com

Erfurt
Über dem Feldgarten 11
99198 Erfurt-Linderbach
Telefon (03 61) 4 20 57 0
Telefax (03 61) 4 20 57 50
nl.erfurt@wuerth.com

Essen
Heinz-Bäcker-Straße 15
45356 Essen
Telefon (02 01) 8 66 45 0
Telefax (02 01) 8 66 45 50
nl.essen@wuerth.com

Esslingen
Flöcher Straße 45
73079 Dettingen
Telefon (0 71 53) 92 94 0
Telefax (0 71 53) 92 94 50
nl.esslingen@wuerth.com

Frankfurt
Weiskirchen, Gewerbegebiet, Ost
Dammersstraße 19
63110 Rodgau
Telefon (0 61 06) 84 01 0
Telefax (0 61 06) 84 01 50
nl.rodgau@wuerth.com

Frankfurt II
Hans-Carl-Straße 338
60314 Frankfurt/Main
Telefon (0 69) 42 69 38 0
Telefax (0 69) 42 69 38 50
nl.frankfurt-main@wuerth.com

Freiburg
Industriegebiet Nord
Miltlerstraße 5
79108 Freiburg
Telefon (07 61) 5 59 66 0
Telefax (07 61) 5 59 66 50
nl.freiburg@wuerth.com

Gera
Gewerbegebiet Bielaebach Ost
Heinrich-Hertz-Straße 14
07552 Gera
Telefon (03 65) 4 37 28 0
Telefax (03 65) 4 37 28 50
nl.gera@wuerth.com

Gießen
Gewerbegebiet Gießen-West
Robert-Bosch-Straße 16
35398 Gießen
Telefon (06 41) 9 62 36 50
Telefax (06 41) 9 62 36 50
nl.giessen@wuerth.com

Göppingen
Industriegebiet Ost
Heilbronner Straße 12
73037 Göppingen
Telefon (0 71 61) 6 80 61 0
Telefax (0 71 61) 6 89 00 0
nl.goepingen@wuerth.com

Goslar
Gewerbegebiet Bassegeige
Alte Heerstraße 15
38638 Goslar
Telefon (0 53 21) 35 19 30 0
Telefax (0 53 21) 3 51 93 50
nl.goslar@wuerth.com

Halle (Saale)
Deltitzcher Straße 70
06112 Halle (Saale)
Telefon (03 45) 6 85 90 10
Telefax (03 45) 5 75 56 54
nl.halle-saale@wuerth.com

Hamburg
Industriegebiet Nettelkrägen
Gutenbergstraße 44
22848 Norderstedt
Telefon (0 40) 53 43 61 50
Telefax (0 40) 53 43 61 50
nl.hamburg@wuerth.com

Hamburg-Süd
Hilmspark Hittfeld
Helmweg 6-16
21183 Hittfeld
Telefon (0 41 05) 58 44 0
Telefax (0 41 05) 58 44 50
nl.seveetal@wuerth.com

Hannover
Gewerbegebiet Godshorn
Bismarckstraße 37
30855 Langenhagen-Godshorn
Telefon (05 11) 7 86 80 90
Telefax (05 11) 7 86 80 50
nl.hannover@wuerth.com

Heidelberg
Gewerbegebiet Rohrbach-Süd
Rechenbacher Straße 1/1
69126 Heidelberg
Telefon (0 62 21) 5 89 88 0
Telefax (0 62 21) 5 89 88 50
nl.heidelberg@wuerth.com

Heilbronn
Dieselstraße 8
74076 Heilbronn
Telefon (0 71 31) 95 56 0
Telefax (0 71 31) 95 56 50
nl.heilbronn@wuerth.com

Ingolstadt
Erngstraße 8
85071 Ingolstadt
Telefon (08 41) 95 67 78 70
Telefax (08 41) 9 31 87 51
nl.ingolstadt@wuerth.com

Jena
Lößelstraße Straße 80
07749 Jena
Telefon (0 36 41) 45 12 0
Telefax (0 36 41) 45 12 50
nl.jena@wuerth.com

Karlsruhe
Prinzstraße 7a
76139 Karlsruhe
Handwerk Holz
Telefon (07 21) 62 52 2 0
Telefax (07 21) 6 25 22 50
nl.karlsruhe@wuerth.com

Kassel
Industriegebiet Waldau West
Otto-Hahn-Straße 18
34123 Kassel
Telefon (05 61) 9 98 68 0
Telefax (05 61) 9 98 68 50
nl.kassel@wuerth.com

Kempten
Messerschmittstraße 16
87437 Kempten
Telefon (08 31) 5 74 48 0
Telefax (08 31) 5 74 48 50
nl.kempten@wuerth.com

Kiel
Seekoppelweg 7a
24113 Kiel
Telefon (04 31) 6 47 40 50
Telefax (04 31) 6 47 40 50
nl.kiel@wuerth.com

Koblenz
Auf dem Hahnenberg 51
56218 Müllheim-Kärlich
Telefon (0 26 30) 94 70 0
Telefax (0 26 30) 94 70 50
nl.koblenz@wuerth.com

Köln
Köhlstraße 43
50827 Köln-Ossendorf
Telefon (0 21) 95 64 42 0
Telefax (0 21) 95 64 42 50
(08 00) 8 65 13 90
nl.koeln@wuerth.com

Künzelsau-Gaisbach
Verkaufsniederlassung
Schillerstraße 22
74653 Gaisbach
Telefon (0 79 40) 15 25 55
Telefax (0 79 40) 15 45 55
nl.gaisbach@wuerth.com

Landshut
Sonnenring 17a
84032 Altdorf
Telefon (08 71) 9 53 71 0
Telefax (08 71) 9 53 71 50
nl.landshut@wuerth.com

Le Stetten
Industriegebiet Stetten
Siemlinger Straße 65
70771 Le Stetten
Telefon (07 11) 22 06 29 0
Telefax (07 11) 22 06 29 50
nl.leintalden-ochtingen@wuerth.com

Leipzig
Industriegebiet Nord
04178 Leipzig/Rückmarsdorf
Telefon (03 41) 4 90 14 40
Telefax (03 41) 4 90 14 40
nl.leipzig@wuerth.com
Würth Service-Container
Am Airport 2000
Postfach 1244
04029 Leipzig
Telefon (03 41) 2 24 19 76
Telefax (03 41) 2 24 19 77
Funk (01 70) 6 33 70 73
ans@wuerth.com

Leonberg
Herlichstraße 10
71229 Leonberg-Ellingen
Telefon (0 71 52) 9 28 24 20
Telefax (0 71 52) 9 28 24 20
nl.leonberg@wuerth.com

Lübeck
Taschnemacherstraße 10
23556 Lübeck (Roggenhorst-Nord)
Telefon (04 51) 8 71 92 0
Telefax (04 51) 8 71 92 50
nl.luebeck@wuerth.com

Magdeburg
Silberbergweg 29
39128 Magdeburg
Telefon (03 91) 2 55 87 70
Telefax (03 91) 2 55 87 50
nl.magdeburg@wuerth.com

Mainz
Carl-Zeus-Straße 13
55129 Mainz-Hochheim
Telefon (0 61 31) 6 27 39 0
Telefax (0 61 31) 6 27 39 50

Manheim
Frauenhoferstraße 7
68309 Mannheim
Telefon (06 21) 7 27 46 0
Telefax (06 21) 7 27 46 50
nl.manheim@wuerth.com

Minden
Ringer Straße 19-51
32427 Minden
Telefon (05 71) 82 97 68 50
Telefax (05 71) 3 96 38 53
nl.minden@wuerth.com

Mönchengladbach
Gewerbegebiet Engellack
Borsigstraße 13
41066 Mönchengladbach
Telefon (0 21 61) 4 77 69 0
Telefax (0 21 61) 4 77 69 50
(08 00) 2 16 14 00
nl.moenchengladbach@wuerth.com

München
Am Lenzteich 2
85377 Ismaning
Telefon (0 89) 96 07 03 0
Telefax (0 89) 96 07 03 50
nl.muenchen-ismanning@wuerth.com

München 2
Rillerstraße 65
80339 München
Telefon (0 89) 43 19 72 0
Telefax (0 89) 43 19 72 50
nl.muenchen-lue@wuerth.com

Münster
Harkortstraße 11
48163 Münster
Telefon (02 51) 2 65 37 0
Telefax (02 51) 2 65 37 50
nl.muenster@wuerth.com

Neubrandenburg
Gneissstraße 8
17036 Neubrandenburg
Telefon (03 99) 4 30 48 0
Telefax (03 99) 4 30 48 50
nl.neubrandenburg@wuerth.com

Nordhausen
Freiherr-vom-Stein-Straße 30c
99734 Nordhausen
Telefon (0 36 31) 4 78 93 0
Telefax (0 36 31) 47 89 50
nl.nordhausen@wuerth.com

Nürnberg
Lankersheimer Straße 10a
90461 Nürnberg
Telefon (09 11) 9 31 92 0
Telefax (09 11) 9 31 92 50
nl.nuernberg@wuerth.com

Offenburg
Robert-Bosch-Straße 2
77626 Offenburg-Elgersberg
Telefon (07 81) 9 69 84 0
Telefax (07 81) 9 69 84 50
nl.offenburg@wuerth.com

Oldenburg
Ammerländer Heerstraße 246
26129 Oldenburg
Telefon (04 41) 2 19 89 0
Telefax (04 41) 2 19 89 50
nl.oldenburg@wuerth.com

Onsbabrück
Haltlicher Masch 12
49084 Onsbabrück
Telefon (05 41) 9 09 01 0
Telefax (05 41) 9 09 01 50
nl.onsabrueck@wuerth.com

Paderborn
Frankfurter Weg 70-72
33103 Paderborn
Telefon (05 231) 8 71 91 30
Telefax (05 231) 8 73 67 50
nl.paderborn@wuerth.com

Papenburg
Siemensstraße 22-24
26871 Papenburg
Telefon (0 49 61) 66 87 0
Telefax (0 49 61) 66 87 50
nl.papenburg@wuerth.com

Pasau
Regensburger Straße 14
94036 Passau
Telefon (08 51) 9 56 62 0
Telefax (08 51) 9 56 62 50
nl.pasau@wuerth.com

Pforzheim
Gewerbegebiet
Wilderanger Höhe
Rastatter Straße 36
75179 Pforzheim
Telefon (0 72 31) 56 86 80
Telefax (0 72 31) 56 87 99
nl.pforzheim@wuerth.com

Potsdam
Am Verkehrtshof 1
14478 Potsdam
Telefon (03 31) 88 88 40
Telefax (03 31) 88 84 50
nl.potsdam@wuerth.com

Regensburg
Franz-Hanzl-Straße 4
93053 Regensburg
Telefon (09 41) 7 83 98 50
Telefax (09 41) 7 83 98 50
nl.regensburg@wuerth.com

Reutlingen
Industriegebiet West
Erdmann-Lassalle-Straße 55
72770 Reutlingen
Telefon (0 71 21) 56 95 0
Telefax (0 71 21) 56 95 50
nl.reutlingen@wuerth.com

Rhein-Sieg
Redcarstraße 2b
53842 Troisdorf-Spich
Telefon (0 22 41) 2 34 02 0
Telefax (0 22 41) 2 34 02 50
nl.rhein-sieg@wuerth.com

Rodgau
siehe bei Frankfurt/Main

Rosenheim
Isarstraße 1A
83026 Rosenheim
Telefon (0 80 31) 2 30 89 0
Telefax (0 80 31) 2 30 89 50
nl.rosenheim@wuerth.com

Rostock
Gewerbegebiet
Neu-Roggentiner-Straße 4
18184 Rostock
Telefon (06 81) 6 60 16 0
Telefax (06 81) 6 60 16 50
nl.rostock@wuerth.com

Saarbrücken
Im Rofeld 21
66115 Saarbrücken
Telefon (06 81) 9 48 65 0
Telefax (06 81) 9 48 65 50
nl.saarbruecken@wuerth.com

Schwäbisch Hall
Industriegebiet Hesselent-Ost
Schillerstraße 41
74523 Schwäbisch Hall
Telefon (07 91) 4 07 23 0
Telefax (07 91) 4 07 23 50
nl.schwaebisch-hall@wuerth.com

Siegen
(Kam-Marienberg)
Hauptstraße 84
57074 Siegen
Telefon (02 71) 6 60 49 0
Telefax (02 71) 6 60 49 29
nl.siegen@wuerth.com

Sinsheim
In der Au 22
74889 Sinsheim
Telefon (0 72 61) 40 21 0
Telefax (0 72 61) 40 21 50
nl.sinsheim@wuerth.com

Stuttgart
Kölner Straße 10
70376 Stuttgart
Telefon (0 71 41) 9 55 73 20
Telefax (0 71 41) 9 55 73 50
nl.stuttgart@wuerth.com

Trier
Ohmstraße 6-8
54292 Trier
Telefon (06 51) 4 36 99 90
Telefax (06 51) 4 36 99 50
nl.trier@wuerth.com

Ulm/Neu-Ulm
Carl-Zeus-Straße 3
89231 Neu-Ulm
Telefon (07 31) 9 78 98 90
Telefax (07 31) 9 78 98 50
nl.ulm-neu-ulm@wuerth.com

Urbach
Schomdorfer Straße 22
73660 Urbach
Telefon (0 71 81) 4 88 64 0
Telefax (0 71 81) 4 88 66 50
nl.urbach@wuerth.com

Villingen-Schwenningen
Industriegebiet Vockenhagen
Heinrich-Hertz-Straße 9
78052 Villingen-Schwenningen
Telefon (0 72 21) 87 19 50
Telefax (0 72 21) 87 19 50
nl.villingen-schwenningen@wuerth.com

Weingarten/Ravensburg
Hähnlehofstraße 5
88250 Weingarten
Telefon (07 51) 5 61 04 0
Telefax (07 51) 5 61 04 50
nl.weingarten-ravensburg@wuerth.com

Weißenburg
Dethenweg Straße 11
91781 Weißenburg
Telefon (0 91 41) 99 55 50
Telefax (0 91 41) 99 55 50
nl.weissenburg@wuerth.com

Wiesbaden
Hafenstraße 17-19
65203 Wiesbaden
Telefon (06 11) 1 86 97 0
Telefax (06 11) 1 86 97 50
nl.wiesbaden@wuerth.com

Wuppertal
Industriegebiet Nord
Nachtstebel
Mödinghofstraße 21
42279 Wuppertal
Telefon (0 20 21) 6 47 71 0
Telefax (0 20 21) 6 47 71 25
nl.wuppertal@wuerth.com

Würzburg
Gewerbegebiet Ost
Sandacker 11
97076 Würzburg
Telefon (09 31) 2 79 89 0
Telefax (09 31) 2 79 89 18
nl.wuerzburg@wuerth.com