

Kinvaro L-80

Montageanleitung / Assembly instructions



F152147588898 - 07/2012

1

Montage / Assembling

Montage: Kinvaro L-80
Mounting: Kinvaro L-80
Montage: Kinvaro L-80

Montaggio: Kinvaro L-80
Montaje: Kinvaro L-80
Montering: Kinvaro L-80




Kinvaro L-80

Montageanleitung / Assembly instructions


F152147588898 - 07/2012

Montage / Assembling




Kinvaro L-80	KH	min. LH	A	Y
Typ 1	350 - 369	312	161	304
Typ 2	370 - 389	332	176	337
Typ 3	390 - 409	352	191	370
Typ 4	410 - 429	372	206	403
Typ 5	430 - 600	392	221	436



Alle Maße in Millimeter.
 All dimensions in millimetres.
 Toutes les dimensions sont en millimètres.
 Tutte le misure sono in millimetri.
 Todas las medidas en milímetros.
 Alla mått i millimeter.



Kinvaro L-80	1	2	3	4	5
X	190	210	230	250	270





Kinvaro L-80	1	2	3	4	5
X	190	210	230	250	270









Kinvaro L-80

Montageanleitung / Assembly instructions

F152147588898 - 07/2012



3





Kinvaro L-80

Montageanleitung / Assembly instructions




F152147588898 - 07/2012

Montage / Assembling







4






5



6



7



8

